

Control4 OS3 Mobile App

You can use your Apple or Android smart phone or tablet to control your new system. Simply download the latest version of "Control4 for OS 3" from the App Store on Apple devices, or the Play Store on Android devices.

Once downloaded, when the app is first loaded you will be asked to sign in with your customer Control4 user name (email address) and password. This is the as your sign in to customer.control4.com.

Note: Your device must be connected to your home WiFi.



Getting Started

with Your Connected Home System



(910) 317-0876
473 Olde Waterford Way, Ste 117
Belville, NC 28451
info@connectedhomenc.com



Remote Quick Start Guide

Turning the system on or off

Pressing the red Control4 logo button will turn your system on and bring up the Control4 on-screen menu. From here, you can use the cursor buttons on the remote to select your desired source, and then press Select. To turn the room off, simply press the "ROOM OFF" button.



Watching a source on your TV

You can select a source to watch using the on-screen menu by pressing the red Control4 logo button on your remote, and selecting the Watch tab on the left hand side of the screen. Alternatively, you can press the WATCH button on the remote, and use the remote's up or down buttons to select a source from the remote's display, and then simply press select.

Playing music

You can select a music source to using the on-screen menu by pressing the red Control4 logo button on your remote and selecting the Listen tab on the left hand side of the screen. Alternatively, you can press the LISTEN button on the remote, and use the remote's up or down buttons to select a source from the remote's display, and then simply press select.

Watching Streaming Video

If your system contains a Roku, you will have a selection under the Watch menu labeled "Apps". Selecting this will present you with a choice of all the apps you currently have installed on your Roku (ex. Netflix, Hulu, etc.)

Switching the remote to another room

If you would like to switch your remote to control another room that is already programmed as part of your system, press the LIST button on the remote. Using the up or down arrows to navigate the menu on the remote's screen, scroll up to the top to highlight the name of the room. From here, simple press the left or right arrows to scroll between the available rooms. Once on the desired room, press the BACK button to exit the menu. Your remote will now control the selected room.

Using the remote to control lights

If you have controllable lights as part of your system, you can use your remote to turn those lights on or off. Simply press the LIST button on the remote, and use the up or down arrow to highlight LIGHTING, and then press SELECT. From here, use the up or down arrows to select the desired light, and use the SELECT button to toggle the light on or off.

Using the on-screen display to control lights

You can also use the system's on-screen display to control your lights. To accomplish this, press the red Control4 logo button to activate the on-screen display. Using the remote's cursor buttons, press left to bring up the menu on the left hand side of the screen. Use the down arrow to select the light bulb icon, and then press SELECT. Use the up or down arrows to select which light you would like to control. The SELECT button can be used to toggle the light on and off, and the left or right arrows can be used to dim or brighten the light (if the light is on a dimmer).

Download the Connected Home Inc.
smart phone app for more helpful
tips!

Simply scan the QR code with your phone!

